

Installation Instructions

NIO-FMMR Series

Flush Mount Mud Ring

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

ITEM NO.	DESCRIPTION
NIO-FMMR-2S	2" IOLITE FLUSH MOUNT MUD RING, SQUARE
NIO-FMMR-4S	4" IOLITE FLUSH MOUNT MUD RING, SQUARE
NIO-FMMR-2R	2" IOLITE FLUSH MOUNT MUD RING, ROUND
NIO-FMMR-4R	4" IOLITE FLUSH MOUNT MUD RING, ROUND

IMPORTANT - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition of the National Electrical Code and all applicable state and local building codes. The final installation must be approved by the appropriate, qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

IMPORTANT - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et à tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.

IOLITE FLUSH MOUNT INSTALLATION STEPS:

1. **FOR NEW CONSTRUCTION:** Trace the cut hole using the plaster frame as a template cut hole with a drywall saw. (Figure 1 and Figure 2)
 2. Plaster the inside top perimeter of the cut hole. (Figure 3)
 3. Place mud ring in cut hole. (Figure 4)
 4. Insert screws provided with the kit.
- NOTE:** DO NOT drive screw into the area of driver. (Figure 6)
5. A professional drywall finisher should complete mud-in. (Figure 7)
 6. Allow plaster to dry. Insert Iolite module to trim. (Figure 8)
 7. Connect Iolite module to driver. (Figure 9)
 8. Insert Iolite trim into housing.
 9. Installation complete.

Figure 1




Figure 2




Figure 3



Figure 4






Figure 5



Note: DO NOT drive screw into the area of driver.

Figure 6





Figure 7



Insert LED module to trim.
Twist clockwise to lock.

Figure 8

